INSTRUCTIONS



HOT HOUSE MINI GREENHOUSE SYSTEM



DESCRIPTION

The Hot House Mini Greenhouse System helps control humidity for better rooting and growth from seedlings, and cutting from your prized plants.

The dome features one top mounted and two side mounted adjustable vents to achieve fresh airflow and adjust desired humidity levels. More airflow will decrease humidity.

INSTRUCTIONS

- 1. Lay down the heat mat on a smooth surface (not cement or steel—they draw too much heat away).
- 2. Place the cut-kit tray directly on top of the heat mat.
- 3. Fill the tray with your favorite growing medium and seeds, then moisten with water (ideally with pH levels around 5.5–6.0).
- 4. Add Root Enhancer (provided with system) per instructions on bottle.
- 5. Place the dome on top of the tray, Rotate the "sun" dials at the top and sides of the dome to open/close the air vents.
- 6. Do not overwater. Keep medium moist, not wet, and do not allow it to dry out completely.
- 7. Allow 4–7 days for seeds to germinate.
- 8. Once plants are several inches tall, transplant and watch them grow.

CK64060 Instructions - rev 4.28.15